

# Automate Your Keysight Test Instruments Using the MATLAB Instrument Control Toolbox

This document will provide step-by-step instructions for using the Instrument Control Toolbox in MATLAB to communicate to a test and measurement instrument. **NOTE:** Although a free trial is available, MATLAB is not free software. A license must be purchased for the MATLAB platform AND the Instrument Control Toolbox for long term use. **NOTE:** The Instrument Control Toolbox is needed in order to communicate to instruments through a VISA.

If you already have the software installed, skip step one.

## 1. Download MATLAB

MATLAB: [http://www.mathworks.com/index.html?s\\_tid=gn\\_logo](http://www.mathworks.com/index.html?s_tid=gn_logo)

Instrument Control Toolbox: <http://www.mathworks.com/products/instrument/index.html>

## 2. Download and Install a VISA


The Virtual Instrument Software Architecture is a very useful tool when communicating to instruments with a PC. In a nutshell, it takes the commands you are using, and converts them into the proper syntax needed for a specific interface (GPIB, USB, LAN, etc..). The programmer simply needs to specify which interface is being used and the VISA will take care of the rest.

Keysight IO Libraries Suite: <http://www.keysight.com/find/iolib>


After downloading and installing the IO Libraries Suite, you will have access to the Keysight Connection Expert:

NOTE: If your PC already has the IO Libraries installed, you do not have to upgrade to the latest version

**CAUTION:** If installing MATLAB on an instrument that already has the IO Libraries installed, do not update the version. This could potentially cause problems with that instrument.



From this software, you can troubleshoot connections, add/delete your connected instruments, and monitor the IO traffic (among other things). You can also grab the VISA address of the instrument here for your program. This will be needed in order to send commands to the instrument and read data from it within MATLAB:



### 3. OPTIONAL\* Download and Install Keysight Command Expert

Keysight Command Expert is a great tool for learning the individual SCPI commands for an instrument and testing the command sequences. There are good descriptions for each command, as well as examples within the GUI. You can then run your SCPI command sequences within Command Expert to make sure the sequence doesn't cause any instrument errors.

If MATLAB is already installed on your PC at the time of the Command Expert installation, the Command Expert software will detect this, and will automatically install a MATLAB add-on. This add-on is a set of MATLAB functions that run Command Expert sequences in MATLAB.

You can also convert your SCPI command sequence directly to MATLAB code.

Keysight Command Expert: <http://www.keysight.com/find/commandexpert>

The screenshot displays the Keysight Command Expert software interface. The top menu bar includes File, Edit, Play, and Help. The interface is divided into several panels:

- Active Instruments:** Shows a list of instruments, with "33522B 2" selected.
- My Instruments:** Lists various instruments including 33250A, 33522B 2, 33622A, 34401A, 34461A, 34970A, 53230A, Bench 33250A, E363x, and N3300A.
- Command Search:** Features a search bar and a tree view of command categories. The "LOAD" command under the "OUTPUT" category is selected.
- Command:** Displays details for the "OUTPUT:LOAD" command. It includes a "Command" field with "OUTPUT:LOAD" and a "Query" field. Below these are input fields for "OUTPUT<num>" and "ohms". A "Perform" button is visible.
- Sequence:** Shows a table of commands in a sequence. The table has columns for Status, Instrument, Code, and Results.

The "Command" panel provides detailed information about the "OUTPUT:LOAD" command, including its syntax and a table of parameters and typical returns.

Parameter	Typical Return
1 $\Omega$ to 10 k $\Omega$ , default 50 $\Omega$	+5.000000000000000E+02


Set output impedance to 300  $\Omega$ :  
OUTP:LOAD 300

Set output impedance to "high impedance":  
OUTP:LOAD INF

- The specified value is used for amplitude, offset, and high/low level settings.
- The instrument has a fixed series output impedance of 50  $\Omega$  to the front-panel channel connectors. If the actual load impedance differs from the value specified, the displayed amplitude and offset levels will be incorrect. The load impedance setting is simply a convenience to ensure that the displayed voltage matches the expected load.

The "Sequence" panel shows a table of commands in a sequence:

Status	Instrument	Code	Results
1	33522B 2	(Connect "33522B 2", "TCPIP0::156.140.159.206::inst0::INSTR", "33500B/33600...)	
2	33522B 2	*RST	
3	33522B 2	:MMEMory:LOAD:DATA1 "Int:\Builtin\Sinc.arb"	
4	33522B 2	:SOURce1:FUNCTion:ARBITrary "Int:\Builtin\Sinc.arb"	
5	33522B 2	:SOURce1:APPLy:ARBITrary 40000,1	
6	33522B 2	:SOURce1:BURSt:STATe 1	
7	33522B 2	:SOURce1:BURSt:INTERnal:PERiod 2	
8	33522B 2	:SOURce1:BURSt:NCYCles 3	
9	33522B 2	:SOURce1:BURSt:MODE TRIGgered	
10	33522B 2	:OUTPut1:LOAD INFINity	



#### 4. Start MATLAB and Start Programming



There are a couple ways to in which you can control an instrument with MATLAB:

##### A. Command Expert

See the previous step. Copy/past code into MATLAB

##### B. Instrument Control Toolbox Application

While the Instrument Control Toolbox is necessary in order to use the VISA functions, using the application itself is not. However, using the application can help get you started with using the VISA function and reading/writing with the instrument.



TCPIP0::156.140.159.206::inst0 (Agilent Technologies,33522B,MY52803925,3.03-1.19-2.00-52-00)

Connection  
 Connection status to 156.140.159.206: **Connected** Cancel Disconnect  
 Last identification request on 02-Apr-2015 17:18:12: Agilent Technologies,33522B,MY52803925,3.03-1.19-2.00-52-00

Communicate Configure Session Log

Sending data

Data type: ASCII

Data format: %s\n

Data to write: \*IDN?

☐ Evaluate in workspace before write

☐ Interpret data as hex string

Query Write

Receiving data

Data type: ASCII

Data format: %c

Size (optional):

Response: data1 (Agilent Technologies...)

☐ Read data as hex string

Read Export Flush

Action	Data	Size	Format
Connecting to	VISA-TCP-0-156.140.159.206-inst0		
Write (Query)	*IDN?	1x5	%s\n
Read (Query)	data1 (Agilent Technologies...)	1x60	%c

TCPIP0::156.140.159.206::inst0 (Agilent Technologies,33522B,MY52803925,3.03-1.19-2.00-52-00)

Connection  
 Connection status to 156.140.159.206: **Connected** Cancel Disconnect  
 Last identification request on 02-Apr-2015 17:18:12: Agilent Technologies,33522B,MY52803925,3.03-1.19-2.00-52-00

Communicate Configure Session Log

```

1 % Find a VISA-TCP-IP object.
2 obj1 = instrfind('Type', 'visa-tcpip', 'RsrcName', 'TCPIP0::156.140.15
3
4 % Create the VISA-TCP-IP object if it does not exist
5 % otherwise use the object that was found.
6 if isempty(obj1)
7     obj1 = visa('AGILENT', 'TCPIP0::156.140.159.206::inst0::INSTR');
8 else
9     fclose(obj1);
10    obj1 = obj1(1)
11 end
12
13 % Connect to instrument object, obj1.
14 fopen(obj1);
15
16 % Communicating with instrument object, obj1.
17 data1 = query(obj1, '*IDN?');
18
  
```

You can copy/paste this code into a MATLAB program from this screen, or save the following code to a “.m” MATLAB file.


## 5. Example Code

You can drop the following code into MATLAB to obtain the instrument's identification string. **Make sure you change the VISA address.** The following code gets the identification string from a Keysight 33500B series function generator.

```
% find all previously created objects
oldobjs = instrfind;

% If there are any existing objects
if (~isempty(oldobjs))
    % close the connection to the instrument
    fclose(oldobjs);
    % and free up the object resources
    delete(oldobjs);
end

% Remove the object list from the workspace.
clear oldobjs;
% create visa object
FGen = visa('agilent', 'TCPIP0::156.140.159.129::inst0::INSTR');
% open a connection to instrument
fopen(FGen);
% get FGen model number
iden = query(FGen, '*IDN?');
disp(iden)
% get rid of the evidence
fclose(FGen);
delete(FGen);
clear FGen;
```



The screenshot shows the MATLAB Command Window with the same code as above. The output of the `disp(iden)` command is circled in red, displaying the identification string: `Agilent Technologies,33522B,MY52802887,3.03-1.19-2.00-52-00`. The prompt `fx >>` is visible at the bottom left.

```
Command Window

% If there are any existing objects
if (~isempty(oldobjs))
    % close the connection to the instrument
    fclose(oldobjs);
    % and free up the object resources
    delete(oldobjs);
end

% Remove the object list from the workspace.
clear oldobjs;
% create visa object
FGen = visa('agilent', 'TCPIP0::156.140.159.129::inst0::INSTR');
% open a connection to instrument
fopen(FGen);
% get FGen model number
iden = query(FGen, '*IDN?');
disp(iden)
% get rid of the evidence
fclose(FGen);
delete(FGen);
clear FGen;
Agilent Technologies,33522B,MY52802887,3.03-1.19-2.00-52-00

fx >>
```

